

## Quick Card

# T-BERD<sup>®</sup>/MTS-2000 Modular Test Set iPhone/iPad Tethering

This procedure describes how to connect a T-BERD/MTS-2000 or SmartOTDR to an iPhone or iPad Hotspot via a USB cable.

### Equipment Requirements:

- T-BERD/MTS-2000 or SmartOTDR equipped with the following:
  - Software Release V16.22 or greater
  - Wireless option for Wi-Fi Connectivity
- iPhone or iPad
  - iOS 6.0 or later
- USB 2.0 Cable to connect iPhone/iPad to T-BERD/MTS-2000



### iPhone setup:



1. Turn on the T-BERD/MTS-2000 or SmartOTDR test set.
2. Turn on the iPhone or iPad to be tethered.
3.  Tap the Settings icon on the iPhone or iPad.
4. Ensure the iPhone/iPad **Personal Hotspot** is set to “Off”.
5. Connect the USB cable from iPhone/iPad to the test set’s USB port.
6. Turn on the iPhone/iPad **Personal Hotspot** by sliding the button right. The button should show green.
7. Select “Trust Computer” on iPhone/iPad (will be a pop-up icon)



Figure 1: iPhone/iPad Settings

### Test Set setup:

The test set will automatically connect to the Personal Hotspot. Once the test set has connectivity, a blue phone icon  will appear in the Status Bar at the top of the screen, and the IP address will be displayed in the **Connectivity** screen. *If the icon does not appear after 30 seconds, turn off and turn on the PERSONAL HOTSPOT on the iPhone/iPad again.*




Figure 2: Home Screen